BarMouse™ 3

Instructions

Connecting your BarMouse:
Connect your BarMouse to one of the computer's USB ports.
No driver is required.

Using your BarMouse:
Position the BarMouse with the scroll wheel, centrally located in front of the keyboard-spacebar. Rotate the bar to move the cursor up or down. Slide it sideways to move the cursor left or right. Press the bar down to get "left mouse-click". If the bar comes to a horizontal end position, the cursor will automatically continue moving in the desired direction.

Properties:
- Adjustable click tension of the bar
- 8 button functionality
- 3 different possible variants of wrist rests
- Programmable buttons without installing or downloading any software
- Clickable bar
- Cursor speed adjustment

Adjusting the cursor speed:
Press down L (1) and Double click (2) at the same time. Continue pressing the two buttons, and with your other hand, click the scroll wheel (3) to adjust the cursor speed.



The DPI setting is changed in 12 steps from 400DPI to 2600DPI. This is indicated with the LEDs. For each click a higher DPI is selected. For every three clicks, the next LED is lit.

			1 2 3 4
DPI 400: LED 1	DPI 600: LED 1	DPI 800: LED 1	■□□□
DPI 1000: LED 2	DPI 1200: LED 2	DPI 1400: LED 2	□■□□
DPI 1600: LED 3	DPI 1800: LED 3	DPI 2000: LED 3	□□■□
DPI 2200: LED 4	DPI 2400: LED 4	DPI 2600: LED 4	□□□■

Adjusting the button functionality
Press down L (1) and R (2) at the same time. Continue pressing the two buttons, and with your other hand, click the scroll wheel (3) to adjust the button functionality.



The LEDs will indicate the change of function as below:



	1	2	3	4	5	6	
	Copy	L	Double click	R	Paste	L	■□□□
Mac setting	Copy	L	Double click	R	Paste	L	□■□□
Bar L-click off	Copy	L	Double click	R	Paste	L	□□■□
	Copy	L	Ctrl	R	Paste	L	□□□■
	Copy	R	Double click	L	Paste	L	■■□□
	Copy	L	Double click	R	Paste	L	■■■□
	L	L	Double click	R	R	L	■■■■
	Copy	L	Double click	R	Paste	Double click	□■■□
	Back in browser	L	Double click	R	Forward in browser	L	□□■■
	Copy	L	Double click	R	Paste	L	■□■□
	Copy	L	Ctrl	R	Paste	Double click	■□□■
	Copy	L	Double click	R	Paste	L	□■□■
							□□□□
							□□□□
							□□□□